

BS EN 1276:2019

Quantitative suspension test for the evaluation of bactericidal activity of chemical disinfectants and antiseptics used in food, industrial, domestic and institutional areas (Phase 2 Step 1)

Microbiological Solutions Limited (MSL) Gollinrod, Walmersley, Bury, BL9 5NB, UK

Angela Davies, CEO

Customer: Direct Independent Imports Ltd Contact name: Callum Unsted Email: Address: Units 23.1 Amber Business Centre, Hilltop Road, Riddings, Derbyshire, DE554BR PO/Quote number: Q003338/4 Report Date: 08/09/2020 Issue Number:1

Megan Barrett Laboratory Manager

Peter Thistlethwaite Technical Projects Manager

The test results on this report refer only to the items tested as supplied by the customer. This report shall not be reproduced except in full and with written approval of Microbiological Solutions Ltd. All reports are archived for a minimum of 2 years. The sample will be retained for 1 month unless otherwise requested in writing.

Microbiological Solutions Ltd Gollinrod Walmersley Bury, BL9 5NB



<u>Scope</u>

The standard method BS EN 1276:2019 describes a suspension test method for establishing whether a chemical disinfectant or antiseptic has or does not have bactericidal activity in the fields described.

The test takes into account practical conditions of application of the product, including contact time, temperature, test organisms and interfering substance, i.e. conditions which may influence its action in practical situations.

The conditions are intended to cover general purposes and to allow reference between laboratories and product types. Each utilization concentration of the chemical disinfectant or antiseptic found by this test corresponds to defined experimental conditions. However, for some applications, the recommendations of use of a product may differ and therefore additional test conditions may need to be used.

Outline of Test Method (Obligatory Test Conditions)

A sample of the test product is diluted in synthetic hard water for products diluted at point of use (or distilled water in the case of ready to use products). A test suspension of bacteria and interfering substance is then added to the dilutions and maintained at 20°C for 1-60 minutes (general purpose disinfection) or 30-60 seconds (hand hygiene products) At the end of the contact time an aliquot is taken, and the bacterial / bacteriostatic activity is immediately neutralised or suppressed by the validated method. The numbers of surviving bacteria in each sample are determined and the reduction is calculated.

The test is performed using *Pseudomonas aeruginosa*, *Escherichia coli*, *Staphylococcus aureus* and *Enterococcus hirae* as standard organisms.

Products can only be tested at a concentration of 80 % or less, as some dilution is always produced by adding the test organisms and interfering substance.

Acceptance Criteria

The product when tested as above shall demonstrate at least a 5 log_{10} (3 log_{10} hand washes) reduction in viable bacterial counts. The test is deemed valid where all control requirements are met.

UKAS Accreditation

This method has been audited by UKAS to the ISO 17025 standard, for tests where no deviations from the standard method are stipulated.

Microbiological Solutions Ltd Gollinrod Walmersley Bury, BL9 5NB



Test identification Reference: J002174-1

	Deviation	
Name of Product	Bactericidal Surface Sanitising & Disinfecting Wipes Solution	
Batch Number & Expiry Date	N/S	
Date of Delivery	24/07/2020	/
Period of Analysis	07/09/2020-08/09/2020	/
Manufacturer / Supplier	Direct Independent Imports Limited	/
Storage Conditions	Ambient	/
Appearance of the Product	Clear liquid	
Neutraliser	N6	
Neutralisation Method	Dilution	
Product Diluent	Distilled water	
Test Concentrations	Neat (80%), Mid-range (50%), Non active (0.1%)	
Experimental Conditions	Clean	
Interfering Substance	Clean 0.3g/l Bovine Albumin	
Test Temperature	20°C ± 1°C	
Temperature of Incubation	Bacteria – 37°C ±1°C for 24hr to 48hrs	
Identification of the Bacterial Strains:	Pseudomonas aeruginosa NCTC 13359 (ATCC 15442)	
	Staphylococcus aureus NCTC 10788 (ATCC 6538)	
	Enterococcus hirae NCTC 13383 (ATCC 10541)	
	Escherichia coli NCTC 10418 (ATCC 10536)	
Contact Times	30 Seconds ± 5s	
Stability and Appearance During Test	No Change Observed	

Deviations from Standard Method

There were no deviations from the standard method

Test Result Summary

The test product received has achieved a >5 log reduction against all bacterial test isolates when tested under the condition stipulated in this report.

See page 2 for acceptance criteria and raw data tables below for complete test results.

Microbiological Solutions Ltd Gollinrod Walmersley Bury, BL9 5NB



Test identification Reference: J002174-1

Validation and Controls

Validation suspension (Nv _o)			Experi	mental cor	ndition	Neutraliser or Filtration Control (B)						Method Validation (C)							
			x=					x	-					x=					x¯=
Vc1	Ps.	49			Vc1	Ps.	56			Vc1	Ps.	49			Vc1	Ps.	23		
	Sa.	80				Sa.	80				Sa.	104				Sa.	73		
	Ec.	32	Ps.	53		Ec.	37	Ps.	62		Ec.	39	Ps.	54		Ec.	49	Ps.	28
	Ent.	41	St.	76		Ent.	26	St.	72		Ent.	59	St.	106		Ent.	30	St.	69
Vc2	Ps.	56	Ec.	31	Vc2	Ps.	68	Ec.	37	Vc2	Ps.	58	Ec.	41	Vc2	Ps.	32	Ec.	50
	Sa.	71	Ent.	37		Sa.	64	Ent.	24		Sa.	107	Ent.	62		Sa.	64	Ent.	30
	Ec.	29				Ec.	37				Ec.	43				Ec.	50		
	Ent.	33				Ent.	22				Ent.	65				Ent.	30		
	$30 \le \overline{x}$ of Nv ₀ ≤ 160 ? \overline{x} of A ≥ 0.5 Nv0						x of B ≥ 0.5 Nv0					\overline{x} of C \geq 0.5 Nv0							
	Yes		Yes						Yes					Yes					

Test Results

SOLUTION PROVIDERS				Test P	roceo	lure a	t concen	tration	s % (\	·/v)					
Test Organism	Suspe	nsion N		Neat											
Pseudomonas	10^6	164;	186	10^0	(0;	0	10^0	0;		0	10^4	16	4;	174
aeruginosa	10^7	24;	36		Na	; <	2.15	N	la ;	<	2.15	I	Na	;	7.23
ATCC 15442	N ₀ :	7.27 V	'alid		R	>	5.12	R		>	5.12	I	۲		0.04
Escherichia	10^6	188;	121	10^0	(0;	0	10^0	0;		0	10^4	10	0;	104
coli	10^7	20;	19		Na	; <	2.15	N	la ;	<	2.15	I	Na	;	7.01
ATCC 10536	N ₀ :	7.20 V	'alid		R	>	5.05	R		>	5.05	I	۲		0.19
Staphylococcus	10^6	268;	240	10^0	(0;	0	10^0	0;		0	10^4	23	6;	220
aureus	10^7	48;	38		Na	; <	2.15	N	la ;	<	2.15	I	Na	;	7.36
ATCC 6538	N ₀ :	7.43 V	'alid		R	>	5.29	R		>	5.29	I	٦		0.07
Enterococcus	10^6	180;	179	10^0	(0;	0	10^0	0;		0	10^4	5	9;	63
hirae	10^7	26;	29		Na	; <	2.15	N	la ;	<	2.15	I	Na	;	6.79
ATCC 10541	N ₀ :	7.27 V	'alid		R	>	5.13	R		>	5.13	I	۲		0.49

Microbiological Solutions Ltd Gollinrod Walmersley Bury, BL9 5NB



Test identification Reference: J002174-1

<u>KEY</u>	
No	Log_{10} number of cfu/ml at the beginning of the contact time = $N/10$
Nvo A	is the number of cfu/ml in the validation test suspension at the beginning of the contact time is the verification of experimental conditions control
В	is the neutraliser toxicity control
С	is method validation
Vc	is the colony forming units counted per 1ml of sample
x	is the average of Vc1 & Vc2
<i>x</i> wm	is the weighted mean of N
Na	Log ₁₀ number of surviving cfu/ml in the test mixture
R	(Ig N_0 – Ig N_a = Ig R) is the calculation for reduction in viability
>	Greater than
≥	Equal to or greater than
<	Less than
≤	Equal to or less than

·

Microbiological Solutions Ltd Gollinrod Walmersley

Bury, BL9 5NB